# Seat Post Di2 battery plugs Installation Instruction

Published - Oct, 2014. ZSP017.v0 © Full Speed Ahead

#### Introduction

Congratulations on your Full Speed Ahead product. Please read these instructions and follow them for correct use. Failure to follow the warnings and instructions could result in damage to product not covered under warranty, damage to bicycle; or cause an accident resulting in injury or death. Since specific tools and experience are necessary for proper installation, it is recommended that the product be installed by a qualified bicycle technician. FSA & Vision assumes no responsibility for damages or injury related to improperly installed components.

### Warranty

Full Speed Ahead (FSA) warrants all FSA, Gravity, Vision, Metropolis and RPM products to be free from defects in materials or workmanship for a period of two years after original purchase unless otherwise stated in the full warranty policy. The warranty is non-transferable and valid to the original purchaser of the product only. Any attempt to modify the product in any way such as drilling, grinding, and painting will void the warranty. For more information on warranty policy and instructions for completing a warranty claim, check out the Full Warranty Policy found at our website: http://www.fullspeedahead.com/techdoc Specification

Item Number / Model Name	E0536 for Post OD Ø 31.6 mm
Item Number / Model Name	E0535 for Post OD Ø 27.2 mm / K-F-L
Item Number / Model Name	F0537 for Post OD Ø 27.2 mm / SL-K

#### **Battery Plugs Installation**

The battery plug is applicable Shimano battery (SM-BTR2). **Tools for Battery Plugs Installation** 

## Cotton glove

1. Connect Shimano Battery adapter.



2. Insert the Shimano battery (SM-BTR2) into battery plug.





If you have questions, please visit our web site technical section: http://www.fullspeedahead.com/contact or contact:

3. Wearing gloves, then fit battery plug by rotation into the end of the seat tube.



4. Turn the battery plug all the way to seatpost.



Do not use wooden or metal hammer to knock the battery plug into the seatpost to avoide damage the battery. Do not apply any grease on the battery plug nor on the inside of seatpost.







METROPOLIS

Full Speed Ahead, USA 12212 Cyrus Way Mukilteo, WA 98275-5702 Tel: 1\_425\_488\_8653 Fax: 1\_425\_489\_1082

Contact

Full Speed Ahead, Europe Via Del Lavoro, 56 20874 Busnago, Milan, Italy Tel: +39\_039\_688\_5265 Fax: +39\_039\_682\_3336

TH INDUSTRIES / FSA Asia NO.6, Wu-gong 8th Rd., Wufeng Dist., Taichung City 41353, Taiwan (R.O.C.) Tel: +886\_4\_2331\_9134 Fax: +886\_4\_2331\_9314

WWW.FULLSPEEDAHEAD.C

Notes: Specifications of product may be changed or improved for performance. Please refer to website periodically for technical updates and revised instructions. Printed in Taiwan.